

Replacement J-Hook Installation

1. Identify type of J-Hook you currently have.
 - a. Old style with only 1 screw (continue to Step 2)
 - b. New style with 2 screws (skip to Step A)
2. Remove rail from post.
3. Unbolt J-Hook and remove it from rail.
4. Using new J-Hook, line up one hole with the existing hole in your rail, and mark the additional hole using a marker.
5. With a ¼ inch drill bit, drill a new hole in your rail.
6. Using the supplied hardware, reinstall the new J-Hook.
7. Slide rail back onto post.

Step A: For old style J-hooks:

1. Remove rail from post.
2. Using an Allen wrench and a 7/16" ratchet or wrench, unbolt J-Hook.
3. Bolt new J-Hook on using the hardware supplied.
4. Reinstall rail.