

Set Up Instructions

VBN1010F Kevlar Practice Net

1. Identify the top Kevlar cable. There are chains on both ends. Remove one of the chains by loosening the quick link and discard. Replace the chain with the snap clip carabineer supplied. When setting up, this carabineer will be clipped to the winch cable.
2. On the same end of the net you installed the carabineer, untie the knot in the bottom rope, remove the black plastic clam cleat and install the rope ratchet supplied.
3. At the opposite end of the net, leave the chain on the upper Kevlar cable. On the bottom rope on this same end, untie the knot and remove the black plastic clam cleat and tie a loop in the rope that will fit on the J-hook on the post. For proper loop see ILLUSTRATION 1
4. There are cords with clam cleats attached to both sides of the net to place around post and tighten to get side net tension.

ILLUSTRATION 1

